



---

## SERVICE SHEETS

---

### FLOOR GRINDER

ART-CUB  
SINGLE PHASE



#### **WARNING**

To reduce the risk of injury, all operators and maintenance personnel must read and understand these instructions before operating, changing accessories, or performing maintenance on this power equipment. All possible situations cannot be covered in these instructions. Care must be exercised by everyone using, maintaining or working near this equipment.




# FLOOR GRINDER

(ELECTRIC MOTOR, SINGLE PHASE 220-240V,  
50HZ, 12.6A, 2.2KW)

PART NO.  
ART-CUB

SERVICE SHEET ART-CUB-SS ISSUE 09.03.2012.




# FLOOR GRINDER

(ELECTRIC MOTOR, SINGLE PHASE 220-240V,  
50HZ, 12.6A, 2.2KW)

PART NO.  
**ART-CUB**

SERVICE SHEET ART-CUB-SS ISSUE 09.03.2012.




# FLOOR GRINDER

(ELECTRIC MOTOR, SINGLE PHASE 220-240V,  
50HZ, 12.6A, 2.2KW)

PART NO.  
**ART-CUB**

SERVICE SHEET ART-CUB-SS ISSUE 09.03.2012.



		<b>FLOOR GRINDER</b>		PART NO.
		SINGLE PHASE		<b>ART-CUB</b>
		<b>PARTS LIST</b>		
SERVICE SHEET ART-CUB. ISS. 09.03.2012.				
ITEM NO.	PART NO.	DESCRIPTION	QUANTITY	
<b>SPARE PARTS</b>				
01-1	ART-01-2001	CUB - 2.2KW SINGLE PHASE MOTOR	1	
01-1-1	ART-01-2011	CUB - ELEC MOTOR FAN COWLING	1	
01-1-2	ART-01-2012	CUB - ELEC MOTOR PLASTIC COOLING FAN	1	
01-1-3	ART-01-2007	CUB - ELEC MOTOR CAPACITOR BOX COMPLETE	1	
01-1-4	ART-01-2009	CUB - ELEC MOTOR START CAPACITOR	1	
01-1-5	ART-01-2010	CUB - ELEC MOTOR RUN CAPACITOR	1	
01-2	ART-01-2006	CUB - ELEC GLAND FOR STARTER BOX & CHASS	1	
	<b>ART-01-1011</b>	<b>CUB - BACK LIFTING HANDLE COMPLETE</b>	<b>1 - Set</b>	
01-3		CUB - BACK LIFTING HANDLE	1	
01-4		CUB - SPRING WASHER,TANG ENDS	4	
01-5		CUB - SCREW, BACK LIFTING HANDLE	4	
	<b>ART-01-1010</b>	<b>CUB - FRONT LIFTING HANDLE COMPLETE</b>	<b>1 - Set</b>	
01-6		CUB - FRONT LIFTING HANDLE	1	
01-7		CUB - SCREW, FRONT LIFTING HANDLE	2	
01-8	ART-01-2004	CUB - KEY, ELECTRIC MOTOR	1	
01-9	ART-01-1003	CUB - CHASSIS	1	
	<b>ART-01-3020</b>	<b>CUB - CHASSIS BOLT SET</b>	<b>1 - Set</b>	
01-10		CUB - BOLT, SQUARE NECK	2	
01-11		CUB - WASHER	1	
01-12		CUB - ADJUSTING HANDLE	1	
01-13		CUB - BOLT, HEX HEAD	2	
01-14		CUB - PLAIN WASHER	3	
01-15		CUB - DOME NUT	3	
	<b>ART-01-3006</b>	<b>CUB - ADAPTOR COMPLETE</b>	<b>1 - Set</b>	
01-16		CUB - ADAPTOR	1	
01-17		CUB - SCREW, HEX HEAD	4	
01-18		CUB - SPRING WASHER,TANG ENDS	4	
01-19	ART-01-1006	CUB - SHROUD HOUSING	1	
	<b>ART-01-1006A</b>	<b>CUB - ALUM WEAR STRIP REMOVABLE COMPLETE</b>	<b>1 - Set</b>	
01-20		CUB - SCREW	2	
01-21		CUB - SPRING WASHER,TANG ENDS	2	
01-22		CUB - ALUMINIUM WEAR STRIP REMOVABLE	1	
	<b>ART-01-1006B</b>	<b>CUB - SHROUD PLASTIC WEAR STRIPS COMPLETE</b>	<b>1 - Set</b>	
01-23		CUB - SHROUD PLASTIC WEAR STRIPS	2	
01-24		CUB - SCREW, PHILIPS RECESS FLAT HEAD	8	
	<b>ART-01-3004</b>	<b>CUB - SHROUD BOLT SET</b>	<b>1 - Set</b>	
01-25		CUB - BOLT, HEX HEAD	2	
01-26		CUB - NUT, HEX	2	

SERVICE SHEET ART-CUB. ISS. 09.03.2012.		<b>FLOOR GRINDER</b>		PART NO.
		SINGLE PHASE <b>PARTS LIST</b>		<b>ART-CUB</b>
ITEM NO.	PART NO.	DESCRIPTION	QUANTITY	

01-27	ART-01-3012	CUB - FLEX DUCT, SHROUD OUTLET	1	
01-28	ART-01-3013	CUB - HOSE CLAMP	2	
	<b>ART-01-3022</b>	<b>CUB - WATER KIT COMPLETE</b>		<b>1 - Set</b>
01-29		CUB - WATER VALVE JOINT	1	
01-30		CUB - WATER VALVE & CONNECTOR ASSEMBLY	1	
01-31		CUB - HOSE NIPPLE, WATER VALVE	1	
		<b>HANDLE ASSEMBLY</b>		
02-1	ART-01-3003	CUB - PLASTIC CAP	1	
02-2	ART-01-1001	CUB - HANDLE - TOP SECTION	1	
02-3	ART-01-3001	CUB - RUBBER HAND GRIP	2	
02-4	ART-01-3007	CUB - SCREW, PAN HEAD	4	
02-5	ART-01-2005	CUB - 2MTR PLUGGED LEAD	1	
02-6	ART-01-2002	CUB - STARTER BOX C/W INT SWITCHES	1	
02-7	ART-01-2006	CUB - ELEC GLAND FOR STARTER BOX & CHASS	1	
02-8	ART-01-2003	CUB - ELECTRIC CABLE	1	
	<b>ART-01-3010</b>	<b>CUB - HANDLE BOLT SET</b>		<b>1 - Set</b>
02-9		CUB - BOLT, HEX	2	
02-10		CUB - SPACER	1	
02-11		CUB - WASHER, PLAIN	4	
02-12		CUB - SCREW, HEX, DOME HEAD	2	
	<b>ART-01-3023</b>	<b>CUB - HANDLE LATCH COMPLETE</b>		<b>1 - Set</b>
02-13		CUB - HANDLE LATCH	1	
02-14		CUB - SPRING WASHER, TANG ENDS	2	
02-15		CUB - BOLT	2	
02-16	ART-01-1002	CUB - HANDLE - BASE SECTION	1	
02-17	ART-01-3009	CUB - PLASTIC SHEATH	1	
02-18	ART-01-3016	CUB - ALLEN KEY	1	
		<b>WHEEL ASSEMBLY</b>		
	<b>ART-01-3011</b>	<b>CUB - AXLE BEARING KIT COMPLETE</b>		<b>2 - Sets</b>
03-1		CUB - SCREW, HEX HEAD	1	
03-2		CUB - SPRING WASHER, TANG ENDS	1	
03-3		CUB - PLAIN WASHER	1	
03-4		CUB - BEARING	2	
03-5	ART-01-3002	CUB - 200MM RUBBER WHEEL	2	
03-6	ART-01-1005	CUB - WHEEL AXLE	2	
03-7	ART-01-1004	CUB - WHEEL AXLE CARRIER	1	
03-8	ART-01-3017	CUB - BOLT	2	

**FLOOR GRINDER**  
SINGLE PHASE  
**PARTS LIST**

PART NO.

**ART-CUB**

SERVICE SHEET ART-CUB. ISS. 09.03.2012.

ITEM NO.	PART NO.	DESCRIPTION	QUANTITY
04-1	ART-01-1007	CUB - GRINDING HUB MOTOR ADAPTOR	1
	<b>ART-01-3014</b>	<b>CUB - GRINDING HUB BOLT SET</b>	<b>1 - Set</b>
04-2		CUB - SPRING WASHER,TANG ENDS	1
04-3		CUB- BOLT, HEX HEAD	1
	<b>ART-01-3021</b>	<b>CUB - GRINDING SHOE ADAPT PLATE BOLT SET</b>	<b>1 - Set</b>
04-4		CUB - NUT, HEX	2
04-5		CUB - SCREW, FLAT HEAD	2
04-6	ART-01-1009	CUB - GRINDING HEAD FLEXIBLE COUPLING	1
	<b>ART-01-3015</b>	<b>CUB - GRINDING HD FLEX COUPLING BOLT SET</b>	<b>1 - Set</b>
04-7		CUB - BOLT, HEX HEAD	2
04-8		CUB - SPRING WASHER,TANG ENDS	2
04-9	ART-01-1008A	CUB - GRINDING SHOE ADAPTOR PLATE	1
04-10	CUB-EZPLATE-250	CUB - EZ CHANGE PLATE	1
04-11	ART-01-3018	CUB - SCREW, BACKING PLATE	4
04-12	N/ A	QUICK FIT SHOE - REFER TO ATTACHED TABLE	
04-13	ART-01-3005	CUB - SEGMENT RETAINING RING	1